


## ➤ What's in the shipping box?

### A. Screws

For assembly to VPD-132/VPD-133/  
VPD-142/VPD-143 only



A1 \* 2




A2 \* 2



A3 \* 2


### B. XV-board



B1: XV-board

B2: Detachable Connector

For assembly to WP-5231/LP-5231  
only



A4 \* 2

### C. Pin Assignment Label

D10	D11	D12	D13	D14	D15	D16	D17	DO.GND	DO.PWR	DO0	DO1	DO2	DO3	DO4	DO5	DO6	DO7
XV107/XV107A																	

### D. Quick Start



➤ **For more information regarding wiring and specifications:**

• **WP-5231**

Product CD:\WP-5231\Document\xv-board\_user\_manual\_vx.x.x.pdf

• **LP-5231**

Product CD:\Napdos\LP-5000\LP-52xx\LP-5231\User\_manual\xv-board\_user\_manual\_vx.x.x.pdf

• **VPD-132/VPD-133/VPD-142/VPD-143**

Product CD:\Document\English\Supported IO Modules\xv-board\_user\_manual\_vx.x.x.pdf

• **Product website**

[http://www.icpdas.com/root/product/solutions/hmi\\_touch\\_monitor/touchpad/xv-board\\_selection.html](http://www.icpdas.com/root/product/solutions/hmi_touch_monitor/touchpad/xv-board_selection.html)

➤ **Technical Support**

- **E-mail:** [service@icpdas.com](mailto:service@icpdas.com)

# ➤ Assembly Chart for VPD-132/VPD-133/VPD-142/VPD-143

<p><b>(1)</b></p>	<p><b>(6)</b></p> <p><b>(A3)</b></p>
<p><b>(2)</b></p>	<p><b>(7)</b></p>
<p><b>(3)</b></p>	<p><b>(8)</b></p>
<p><b>(4)</b></p> <p><b>(A1)</b></p> <p><b>(A2)</b></p>	<p><b>(9)</b></p> <p><b>(B2)</b></p>
<p><b>(5)</b></p> <p><b>(B1)</b></p>	<p><b>(10)</b></p> <p><b>(C)</b></p>

## ➤ Assembly Chart for WP-5231/LP-5231

